

4.9.4 Wiring diagrams

Wiring diagram RM 5xx0 without interior lighting




Fig. 38

Connections

- A = ground heating element 12VDC
- B = plus heating element 12VDC